

# User Manual

## EDX-B02D

### 2-Channel Curtain Controller



## INDEX

1. Introduction.....	2
1-1 Feature .....	2
1-2 Specification.....	2
1-3 Dimension.....	3
1-4 Panel Introduction.....	3
1-5 Wiring Diagram.....	4
2. Operation .....	5
2-1 Initialization.....	5
2-2 DMX Address Setting.....	5
2-3 Motor Control .....	6
2-4 Accept/Refuse DMX Signal.....	6
2-5 ID No. Setting.....	7
2-6 Zone Setting.....	7
2-6-1 Single/Multi Zone Setting .....	7
2-6-2 Single Zone Setting.....	7
2-6-3 Multi Zone Setting.....	8
2-7 Scene Setting.....	8
2-8 Scene Save and Recall .....	9
2-9 Scene Duration Setting.....	9
2-10 Motor Rotate Setting.....	10
2-11 Check Software Version.....	10
Limited Warranty.....	11

# 1. Introduction

---

## 1-1 Feature

---

- Standard DMX control. When the DMX value higher than 75%, curtain motor start to rotate clockwise; when the DMX value lower than 25%, curtain motor start to rotate counterclockwise; When the DMX value is in the range of 25%–75%, the curtain motor stop rotating.
- 2 dry contacts output control the curtain motor rotate clockwise and counterclockwise.
- Accept ECP control panel.
- Can save 6 scenes.

## 1-2 Specification

---


- Power supply: AC 100-240V 50Hz-60Hz
- Protocol: DMX-512/RS-485
- Signal connector: 6P6C PHONE JACK(RJ11) \*2, 4Pin green terminal
- Installation: track-mounted
- Dimension: 198 (W) x 90 (H) x 62 (D) mm
- Weight: 650g

# Lite-Puter

## 1-3 Dimension




## 1-4 Panel Introduction




1	Power supply : AC 100-240V	2	LED display
3	DMX: confirm button; FCN: function button; ▲▼◀▶ direction button		
6	Power indicator	4、5、8	Signal input: DMX-512/RS485
7	Communication indicator	9	Counterclockwise shortcut button and indicator
10	clockwise shortcut button and indicator	11	Control output

## 1-5 Wiring Diagram

AC Motor Wiring:



## DC Motor Wiring:



## 2. Operation

### 2-1 Initialization

STEP-1: hold **▲** and **▼** to power the device until LED displays:

F20-

STEP-2: Press **DMX** to initial:

ELF

STEP-3: then enter the main screen:

0101

Press **FCN** after STEP-2 can stop initialization.

### 2-2 DMX Address Setting

Standard DMX console can output 512 channels and EDX-B02D can use consecutive 2 channels out of them as the output channel. In these 2 channels, the first channel No. is start channel address.

## Lite-Puter

---

STEP-1: On the main page, press **【DMX】** + **【▲】** or **【▼】** to set the DMX address.  
For example, change the DMX address from 001 to 003



When the DMX signal inputs, LED displays:



STEP-2: Release button to back.

## 2-3 Motor Control

---

On the main page , hold **【▲】** to start the motor rotate clockwise ; hold **【▼】** to start the motor rotate counterclockwise; release **【▲】** or **【▼】** , the motor will stop rotating.

## 2-4 Accept/Refuse DMX Signal

---

STEP-1: On the main page, press **【FCN】** 3 times to enter the screen:



STEP-2: Press **【▲】** or **【▼】** to select ON/OFF:



*In which:*

*ON—— Refuse external DMX signal*

*OFF—— Accept external DMX signal*

STEP-4: After setting, press **【DMX】** to save, press **【FCN】** to exit.

## 2-5 ID No. Setting

Each EDX series device must have a ID No.. When one device is working alone, there is no need to adjust the ID No., but when several devices are working together, each device must have a different ID No.

STEP-1: On the main page, press **【FCN】** twice to enter ID NO. setting.



STEP-2: Press **【▲】** or **【▼】** to change ID NO.. (Up to 999)

STEP-3: After setting, press **【DMX】** to save, press **【FCN】** to exit.

## 2-6 Zone Setting

Definition of zone: The device must set the Zone No. before using, which consists of two parts, one is the zone no. and another is the start channel address.

### 2-6-1 Single/Multi Zone Setting

STEP-1 : On the main page, press **【FUNC】** 7 times to enter Zone setting.



STEP-2: Press **【▲】** or **【▼】** to choose ON or OF



*In which:*

*ON—Multi Zone state*

*OF—Single Zone state*

STEP-3: After setting, press **【DMX】** to save, press **【FCN】** to exit.

### 2-6-2 Single Zone Setting

STEP-1: On the main page, press **【FCN】** once to enter single zone setting. The cursor will blink:





## Lite-Puter

---

STEP-2: Press **【▲】** or **【▼】** to change the zone no. (Up to 99 Zones)

STEP-3: Press **【◀】** or **【▶】** to shift between zone and start channel option; press **【◀】** to shift to start channel option, and then press **【▲】** or **【▼】** can modify the zone No. (Up to 99)



Blink, start channel is 1

STEP-4: After setting, press **【DMX】** to save, press **【FCN】** to exit.

### 2-6-3 Multi Zone Setting

STEP-1: On the main page, press **【FCN】** 8 times to enter multi zone setting. The cursor will blink:



Blink, channel is 1

STEP-2: Press **【▲】** or **【▼】** can modify channel;



STEP-3: Press **【◀】** or **【▶】** to shift to zone select state. The cursor will blink:



Blink, zone is 1

STEP-4: Press **【▲】** or **【▼】** can choose channel zone (Up to 99 Zones);

STEP-5: Press **【◀】** or **【▶】** to shift to start channel select. The cursor will blink in the start channel option:



Blink, start channel is 1

STEP-6: Press **【▲】** or **【▼】** can choose start channel (Up to 255)

STEP-7: After setting, press **【DMX】** to save, press **【FCN】** to exit.

### 2-7 Scene Setting

---

STEP-1: On the main page, press **【FCN】** five times to enter channel edit status.



Blink, channel 1

## Lite-Puter

---

STEP-2: Press **【▲】** or **【▼】** to select channel

STEP-3: Press **【◀】** or **【▶】** to shift to LEVEL setting status of channel



Blink, the current LEVEL is 50, the motor stops.

STEP-4: Press **【▲】** or **【▼】** to modify LEVEL 0-FL of channel



Blink, the current LEVEL is 75, the motor rotates clockwise.

## 2-8 Scene Save and Recall

---

STEP-1: According to 2-7, press **【DMX】** to enter scene save screen:



STEP-2: Press **【▲】** or **【▼】** to select the desired scene No., and save the current channel status as any scene (SC1-6)



STEP-3: After setting, press **【DMX】** to save, press **【FCN】** to exit.

## 2-9 Scene Duration Setting

---

STEP-1: On the main page, press **【FCN】** four times to enter Scene Duration Setting.  
The cursor will blink:



Blink, scene 1

STEP-2: Press **【▲】** or **【▼】** to select scene No., and can select any scene (SC1-6)



STEP-3: Press **【◀】** or **【▶】** to shift to scene duration setting status:



Blink, scene duration scene is 10s

STEP-4: Press **【▲】** or **【▼】** to select scene duration(1-99s) or any one of infinity.

## 2-10 Motor Rotate Setting

---

STEP-1: On the main page, press **【FCN】** six times to enter motor operation status setting. The cursor will blink:



Blink, channel 1

STEP-2: Press **【▲】** or **【▼】** to select channel



STEP-3: Press **【◀】** or **【▶】** to shift to motor rotate setting status:



Blink, UP means motor rotates clockwise

STEP-4: Press **【▲】** or **【▼】** to select UP/DOWN



*In which :*

*UP— motor rotates clockwise*

*DOWN— motor rotates counterclockwise*

STEP-5: Press **【◀】** or **【▶】** to shift to motor operation setting screen:



Blink, motor operating time is 10s

STEP-6: Press **【▲】** or **【▼】** to select motor rotate time(1-99s) or any one of infinity

STEP-7: After setting, press **【DMX】** to save, press **【FCN】** to exit.

## 2-11 Check Software Version

---

On the main page, press **【FUNC】** nine times to check the current software version.



# Limited Warranty

---

1. Lite-Puter is only responsible for the product itself.
2. Lite-Puter warrants to repair any manufacturing defects within one year of distribution date.
3. Lite-Puter does not offer on-site service. Should a defect appear in Lite-Puter's product, please deliver the product to local distributors or Taiwan Headquarters.
4. This Limited Warranty does not cover:
  - a. Any fault caused by false usage or imprudence (collision, inadequate installation or adjustment, insufficient ventilation, or improper repairs)
  - b. Force majeure factors (flooding, earthquake, volcanic eruption, or other factors beyond Lite-Puter's control).
  - c. Labor costs incurred in diagnosis of defects; installation, reinstallation, wiring, rewiring, repairing, adjustment, or reprogramming of a product; or any other consequential expenses.
  - d. Other Lite-Puter or non-Lite-Puter products or devices offered, packaged, or sold with the product.
5. Lite-Puter does not warrant that the product will operate without interruption or free of error.

### **World Headquarters :**

Lite-Puter Enterprise Co., Ltd.

Address: 11F, No. 189, Gangqian Rd., Neihu Dist., Taipei City 11494, Taiwan.

Tel: +886-2-27998099

Fax: +886-2-27993828

Website: [www.liteputer.com.tw](http://www.liteputer.com.tw)

E-mail: [sales@liteputer.com.tw](mailto:sales@liteputer.com.tw)

### **Shanghai Factory :**

Lite-Puter Technology ( Shanghai ) Co.,Ltd.

Address: No. 375, Xingmei Road, Minhang Dist., Shanghai, China

Zip Code: 200237

Tel: +86-21-54408210

Fax: +86-21-54403376

Website: [www.liteputer.com.tw](http://www.liteputer.com.tw)

E-mail: [sales\\_china@liteputer.com.tw](mailto:sales_china@liteputer.com.tw)