

DMX CHARTS |

RDM Model ID: 0xD128

RDM Personality ID List

ID	DMX Mode
1	UNO
2	DUO
3	BASIC
4	STANDARD
5	EXTENDED

Channel	UNO	DUO	BASIC	STANDARD	EXTENDED
1	DIMMER	DIMMER	DIMMER	DIMMER	DIMMER
2		CCT	WARM WHITE	DIMMER FINE	DIMMER FINE
3			COLD WHITE	STROBE	STROBE
4				CCT	CCT
5				CCT FINE	CCT FINE
6					CROSSFADE
7					WARM WHITE
8					WARM WHITE FINE
9					COLD WHITE
10					COLD WHITE FINE
11					FUNCTION

UNO	DUO	BASIC	STANDARD	EXTENDED	Function	DMX Value	Default
1	1	1	1	1	DIMMER 0~100%	000 ÷ 255	000
			2	2	DIMMER FINE	000 ÷ 255	000
			3	3	STROBE Close Strobe from slow to fast Open Pulse in from slow to fast Open Pulse out from slow to fast Open Randon from slow to fast Open	000 ÷ 001 002 ÷ 062 063 ÷ 064 065 ÷ 125 126 ÷ 127 128 ÷ 188 189 ÷ 190 191 ÷ 251 252 ÷ 255	255
	2		4	4	CCT 2700K - 2800K 2800K - 2900K 2900K - 3000K 3000K - 3100K 3100K - 3200K 3200K - 3300K 3300K - 3400K 3400K - 3500K 3500K - 3600K 3600K - 3700K 3700K - 3800K 3800K - 3900K 3900K - 4000K 4000K - 4100K 4100K - 4200K 4200K - 4300K 4300K - 4400K 4400K - 4500K 4500K - 4600K 4600K - 4700K 4700K - 4800K 4800K - 4900K 4900K - 5000K 5000K - 5100K 5100K - 5200K 5200K - 5300K 5300K - 5400K 5400K - 5500K 5500K - 5600K 5600K - 5700K 5700K - 5800K 5800K - 5900K 5900K - 6000K 6000K - 6100K 6100K - 6200K 6200K - 6300K 6300K - 6400K 6400K - 6500K	0 ÷ 7 7 ÷ 13 13 ÷ 20 20 ÷ 27 27 ÷ 34 34 ÷ 40 40 ÷ 47 47 ÷ 54 54 ÷ 60 60 ÷ 67 67 ÷ 74 74 ÷ 81 81 ÷ 87 87 ÷ 94 94 ÷ 101 101 ÷ 107 107 ÷ 114 114 ÷ 121 121 ÷ 128 128 ÷ 134 134 ÷ 141 141 ÷ 148 148 ÷ 154 154 ÷ 161 161 ÷ 168 168 ÷ 174 174 ÷ 181 181 ÷ 188 188 ÷ 195 195 ÷ 201 201 ÷ 208 208 ÷ 215 215 ÷ 221 221 ÷ 228 228 ÷ 235 235 ÷ 242 242 ÷ 248 248 ÷ 255	000
			5	5	CCT FINE	000 ÷ 255	000
				6	CROSSFADE CCT to WW/CW 0~100%	000 ÷ 255	000
		2		7	WARM WHITE 0~100%	000 ÷ 255	255
				8	WARM WHITE FINE	000 ÷ 255	255
		3		9	COLD WHITE 0~100%	000 ÷ 255	255

UNO	DUO	BASIC	STANDARD	EXTENDED	Function	DMX Value	Default
				10	COLD WHITE FINE	000 ÷ 255	255
					FUNCTION		
					No Function	000 ÷ 001	
					Display Backlight On	002 ÷ 003	
					Display Backlight 10 s	004 ÷ 005	
					Display Backlight 20 s	006 ÷ 007	
					Display Backlight 30 s	008 ÷ 009	
					Display Flip Regular	010 ÷ 011	
					Display Flip Top Down	012 ÷ 013	
					Display Key Lock ON	014 ÷ 015	
					Display Key Lock OFF	016 ÷ 017	
					Dimmer Mode Linear	018 ÷ 019	
					Dimmer Mode S-Curve	020 ÷ 021	
					Dimmer Mode Square Law	022 ÷ 023	
					Dimmer Mode Inverse Square Law	024 ÷ 025	
					Dimmer Speed Auto	026 ÷ 027	
					Dimmer Speed Slow	028 ÷ 029	
					Dimmer Speed Medium	030 ÷ 031	
					Dimmer Speed Fast	032 ÷ 033	
					White Calibration OFF	034 ÷ 035	
					White Calibration MANUAL	036 ÷ 037	
					LED Frequency 600 Hz	038 ÷ 039	
					LED Frequency 1200 Hz	040 ÷ 041	
					LED Frequency 2000 Hz	042 ÷ 043	
					LED Frequency 4000 Hz	044 ÷ 045	
				11	LED Frequency 6000 Hz	046 ÷ 047	000
					LED Frequency 25 kHz	048 ÷ 049	
					DMX Lost Blackout	050 ÷ 051	
					DMX Lost Hold	052 ÷ 053	
					DMX Lost Stand Alone	054 ÷ 055	
					Fan Auto	056 ÷ 057	
					Fan Silent	058 ÷ 059	
					Fan High	060 ÷ 061	
					Fan OFF	062 ÷ 063	
					Stand Alone Master Dmx	064 ÷ 065	
					Stand Alone Master No Dmx	066 ÷ 067	
					Stand Alone Slave	068 ÷ 069	
					Stand Alone Effect	070 ÷ 071	
					Stand Alone CCT	072 ÷ 073	
					Stand Alone WW+CW	074 ÷ 075	
					Stand Alone White Presets	076 ÷ 077	
					Stand Alone Fixed Color	078 ÷ 079	
					Stand Alone Color Temperature	080 ÷ 081	
					Stand Alone Manual Color	082 ÷ 083	
					Menu Stand Alone	084 ÷ 085	
					Output Control Constant	086 ÷ 087	
					Output Control Dynamic	088 ÷ 089	
					RESERVED	090 ÷ 253	
					FACTORY DEFAULT OF ALL CONTROLLED FUNCTION	254 ÷ 255	