

# ACCU DECOLITE IP

## SETUP WIRELESS DMX

### TRANSMITTER MODE : (LED = BLUE)

- Keep the [ID] button pressed while powering up the WIRELESS part of the ACCU DECOLITE IP. The status LED will become WHITE shortly, than turns BLUE, RED or GREEN (the last selected mode).
- Choose BLUE by pressing the [ID] button shortly.
- Once BLUE selected, press the [ID] button for 3 seconds to confirm the transmitter mode.
- The status LED will turn white and after a few seconds turns BLUE (blinking if there is no DMX signal present)
- The unit is now in transmitter mode.

### RECEIVER MODE : (LED = GREEN)

- Keep the [ID] button pressed while powering up the WIRELESS part of the ACCU DECOLITE IP. The status LED will become WHITE shortly, than turns BLUE, RED or GREEN (the last selected mode).
- Choose GREEN by pressing the [ID] button shortly.
- Once GREEN selected, press the [ID] button for 3 seconds to confirm the receiver mode.
- The status LED will turn white and after a few seconds turns RED (fast blinking if there is no signal present) or GREEN (when the receiver is paired with a transmitter).
- The unit is now in receiver mode.
- Release the receiver from any universe (transmitter) by pressing the [ID] button for 5 seconds. The status led now turns WHITE. The unit is now ready to be paired with a transmitter.

### PAIRING TRANSMITTER AND RECEIVER(S) :

**First of all : prepare transmitter and receiver(s) as described above.**

- Press the [ID] button on the transmitter. The BLUE led starts blinking and the led on the receiver(s) starts blinking GREEN at the same time.  
After a few seconds the leds stop blinking. The transmitter and receiver(s) are now paired.