



UDA-49A Active/Passive UHF UDA-49P Directional Antenna

Thanks for choosing JTS Active/Passive UHF Directional Antenna. In order to obtain the best efficiency, you are recommended to read this manual before applying.




UDA-49A/UDA-49P
Active/Passive UHF Directional Antenna



59010-067-04

UDA-49A/UDA-49P

is an active/passive directional antenna which enhances the reception of the desired signal and rejects the unwanted RF signal. UDA-49A provides integrated antenna booster for use of long antenna extension cable.



SPECIFICATION

UDA-49A

Active UHF Directional Antenna

- * Frequency Band: 470~960 MHz
- * Effective Working Angle: 100 degree
- * Antenna Gain: 10dB
- * Net Weight: 400g
- * Power Supply: 12V, 50mA
- * Booster Gain: 3dB/10dB Selectable

UDA-49P

Passive UHF Directional Antenna

- * Frequency Band: 470 ~ 960 MHz
- * Effective Working Angle: 100 degree
- * Antenna Gain: 10dB
- * Net Weight: 400 grams


INSTALLATION

1. Select the booster gain according to the antenna cable length (type RG58U) [UDA-49A only]:
3dB: 15 meters max.;
10dB: 50 meters max.

**For UDA-49P cable length is upto 5 meters.*

2. Connect one end of antenna cable to the antenna. Then, mount the antenna onto a mic. stand or suspend it from the ceiling.
3. Connect the other end of cable to the wireless receiver or antenna distribution system.
4. The LED will light up, when the power is supplied. [UDA-49A only]
5. Walk around and find out the optimum location for UDA-49A/UDA-49P.

**For better performance, it is recommended to use two antennas with diversity wireless systems.*



DIMENSIONS(m/m)

